

Dear Customer,

Thank you for your spike purchase from Brass & Granite Audio. The following information may assist you in insert installation if your speakers do not already have inserts installed. The inserts accompanying these spikes are screw in style, making it very quick and easy for speaker spike installation. Remember to always consider internal components before drilling into your speakers. Brass & Granite Audio will be held harmless for damages sustained from insert installation and speaker a void of speaker warrantee because of it.

I always suggest installing an insert into a piece of scrap wood before installing the inserts into your speakers. This gives you the feel for what to look for. Because the insert is a screw in type you will be able to unscrew and use again with your project.

1. Layout and pre-drill the locations for your spikes on the bottom of your speakers to an approx depth of .65". I use a 1/8" drill bit for this.
2. Using a 9mm drill (3/8" will work) drill the pre-drilled holes to a depth of at least .65".



3. Place the insert into the opening of the hole and screw insert into hole using a M6 or 7/32 Allen wrench. Screw so that insert is flush with bottom of speaker.



4. Screw in spikes!!





When placing speaker on carpet I recommend finding the spot were you want the speaker and then apply weight to the top of the speaker until the spikes pierce through the carpet and pad until they reach the subfloor.

Feel free to e-mail us with any questions at paul@oregondv.com.

Sincerely,

Paul Stepanek